

## Forend Grip (Chainsaw)

The Chainsaw-style Forend Grip is designed to mount on a Picatinny rail and provides a stable and ergonomic grip with a pistol grip shotgun.



**Refer to your firearm's manual for complete safety information. Manuals for Mossberg firearms are available at [www.mossberg.com](http://www.mossberg.com) or by contacting the Product Service Center.**



**Do not use the Forend Grip alone to carry your firearm. The weight of the firearm may allow the action to close and point the firearm in an unsafe direction.**



**Before use, ensure that the Forend Grip is securely tightened to the Picatinny rail using all three screws provided. The recommended torque of the screws is 30 – 35 inch pounds.**



**Before use, ensure that the locking lugs on the Forend Grip are engaged into a slot in the Picatinny rail. Failure to engage the locking lugs can result in damage to the forend grip or the Picatinny rail and may result in personal injury.**



**Before use, ensure that the Forend Grip is securely attached to the forend. The photo below shows a typical position and orientation of the forend grip.**

